





# MAXIM® DUAL ARM OPERATORS (LOW PROFILE)

FIG. 9 APPLICATION OF STANDARD MAXIM DUAL ARM OPERATOR (CONTINUED)  
(SILL MOUNT VERSION) (LOW PROFILE)



**11661.XX**  
**BRACKET PLACEMENT**



**32384.XX**  
**TRACK PLACEMENT**

HARDWARE SHOWN FOR LEFT HAND WINDOW, SEE FIG.6	
PART NUMBER	DESCRIPTION
50.01.XX.011	DUAL ARM OPERATOR
11661.XX	STUD BRACKET
32384.XX	TRACK
14.97.00.XXX	WASHABILITY HINGE
11454.XX	CONTOUR HANDLE
31882	GASKET (PVC)

HINGE	"A"
14.97.00.XXX 14.12.00.XXX	.422 [10.7 mm]
OTHER 14 SERIES CASEMENT HINGES	.375 [9.5 mm]


NOTES:

1. STUD BRACKET 11661.XX AND 11662.XX WILL BE PLACED IN THE SAME LOCATION FOR BOTH THE ENCORE DUAL ARM OPERATOR AND THE ENCORE DYAD OPERATOR.

2. HOLD THIS DIMENSION AS CLOSE TO THE MINIMUM AS MANUFACTURING TOLERANCES ALLOW. A CLOSE FITTING CUT-OUT HELPS TO STABILIZE THE OPERATOR AGAINST ROCKING.

3. GASKET 32658 IS REQUIRED ON PVC AND METAL PROFILES FOR AN IMPROVED AIR AND WATER SEAL

**FIG. 10 MAXIM STANDARD DUAL ARM OPERATOR  
(SILL MOUNT VERSION) (LOW PROFILE)**




**RECOMMENDED SCREWS:**

(QTY 6)(PN 19240.XX) #8 X 1 FLAT HEAD  
SHEET METAL SCREWS (SEE TRUTH TIPS  
FOR MORE INFORMATION)


(QTY 2)REAR MOUNT:#8-32 X 3/8 PAN HEAD  
MACHINE SCREW PN 19545.XX

**FIG. 11 MAXIM COVER 41211.XX /HANDLE 11329.XX(LH) (SHOWN)**



# MAXIM® DUAL ARM OPERATORS (LOW PROFILE)

FIG. 12 TRACK 32384.XX




**RECOMMENDED SCREWS:**

(QTY 4) (PN 19070.XX) #7 X 1/2 FLAT HEAD UNDERCUT SHEET METAL SCREW (SEE TRUTH TIPS FOR MORE INFORMATION)

FIG. 13 STUD BRACKET 11661.XX(LH) (SHOWN), 11662.XX(RH)

HAND OF BRACKET DOES NOT NECESSARILY MATCH HAND OF OPERATOR



**RECOMMENDED SCREWS:**

(QTY 4) (PN 19205.XX) #8 X 1/2 SHEET METAL SCREW (SEE TRUTH TIPS FOR MORE INFORMATION)